

Ultra-Oil & Debris Blocker

Part# 9380-9387

INSTALLATION INSTRUCTIONS



8" One piece combination elbow and adapter (Part# 9380): (1.) Place adapter end in the outfall pipe opening (2.) Squeeze the adapter together (the adapter is of split design, to allow this procedure) and push into the outfall pipe. (3.) Push the elbow/adapter combination into the outfall pipe.. as far as it will go. The tension from the released adapter portion is all that is required, to hold the elbow/adapter combo in place. Also allows for easy removal, should jetting of the outfall line become necessary. In addition, the design eliminates the need to identify the outfall pipe type, as it fits all 8" pipe, in spite of a variance in I.D.

10" elbow and adapter (Part# 9381-9383): The 10" elbow and adapter are provided in separate pieces, as right and left entry elbows are available, as well as the center entry. This is due to the fact, that 10" outfall pipes are occasionally placed to the extreme right or left of the catch basin. Most common, however, is the center entry. (1.) Snap the elbow and the adapter together. (2.) Follow the same steps, as with the 8" Oil & Debris Blocker (see above)

12" elbow and adapter (Part# 8384): The 12" elbow and adapter are provided in separate pieces. Snap the elbow and adapter together. A nitrile o-ring is provided with the two pieces, and is rolled onto the adapter, at the end that is to be inserted into the outfall pipe. Roll the o-ring onto the adapter, about 2-3"...Slide the adapter into the outfall pipe...push the adapter/elbow into the outfall pipe. The o-ring will roll in, as well, forming a seal and snug fit. There is a considerable variance in I.D. between ductile iron pipe and ads ... so a 1/2" O.D. o-ring and a 7/16" o-ring are provided with each 12" elbow and adapter ordered.

11542 Davis Creek Court • Jacksonville, FL 32256

800.353.1611 • www.Stormwater-Products.com



OTHER PRODUCTS AVAILABLE FROM ULTRATECH



Ultra-Spill Berm



Ultra-Hard Top



Ultra-Dewatering Bag