



## Ultra-Mini Sprayer®

Ultra-Mini Sprayers (PN 4122, 4134, 4138)  
Replacement Cartridges (PN 4126, 4135, 4139)

### Quick Start Guide for Ultra-Ever Dry

1. Use appropriate PPE (gloves, respirator, goggles, paint suit, etc.)
2. Prepare and clean surfaces prior to coating for better adhesion.
3. Shake or mechanically mix the Bottom Coat for 5-10 minutes prior to application.
4. For convenience, the Ultra-Mini Sprayer is sold in two-packs, so you can use one for the Bottom Coat and one for the Top Coat.
5. Apply thin, even coats - do not pool the coating.
6. Allow the Bottom Coat to dry for at least 30 minutes before applying the Top Coat (do not apply Top Coat if the Bottom Coat is still wet.)
7. Clean the Ultra-Mini Sprayer by spraying a small amount of xylene into a rag or waste container and allow the sprayer to dry before reusing the sprayer.
8. Shake or mechanically mix the Top Coat for 3-5 minutes prior to application.
9. Allow the Top Coat to dry for at least 30 minutes prior to challenging with liquid - allowing the Top Coat to dry longer (even overnight) can improve results.
10. Clean the Ultra-Mini Sprayer by spraying a small amount of xylene into a rag or waste container and allow the sprayer to dry before reusing the sprayer.
11. Dispose of xylene and cleaning materials according to local regulations.
12. If the Ultra-Mini Sprayer clogs during application, the filter at the bottom of the dip tube can be removed.
13. If the Ultra-Mini Sprayer clogs after the filter is removed, the sprayer can be back-flowed by depressing the trigger while the nozzle is covered.
14. Refer to the specific instructions for Ultra-Ever Dry and the Ultra-Mini Sprayer (inside panels of the box) for more detailed information.

