



Ultra-Safe Connect[®]

Part# 8170 - 2" Collar • Part# 8171 - 3" Collar

INSTRUCTIONS



The Ultra-Safe Connect is installed after a line shut off valve. A short pipe or nipple is installed after the valve and into the back of the unit. The entire unit must be spun onto the line pipe.

The lid is then opened and connection made inside the unit so that spills are contained within the tub. The line or hose being connected is designed to rest in the scoop front of the tub for support. The lid can then be partially closed if desired.

The Safe Connect is designed for drips and leaks, not catastrophic line/connection failures. Inspect for spills before and after use, and monitor during filling process to prevent overflow in the case of a large leak (exceeding unit's capacity).



UltraTech International, Inc.

1-904-292-1611

1-800-353-1611

www.SpillContainment.com

11542 Davis Creek Court, Jacksonville, Florida 32256 USA